



108 Chelsea Grove Court • Pasadena, Maryland 21122 Satellites offices: Salisbury • Frederick • Randallstown  
410-255-0800 (phone) • 410-255-3522 (fax) • [www.fittingsbymichele.com](http://www.fittingsbymichele.com) • [fittingsbym@hotmail.com](mailto:fittingsbym@hotmail.com)

## HUMAN HAIR WIG CARE INSTRUCTIONS

**PUTTING ON YOUR WIG:** Hold wig with inside facing up and front hairline towards your body. Place thumbs on adjustable elastic tabs at the nape and gently pull wig on like a cap keeping your ears free. Push hairline of wig to match your natural hairline, using side tabs to adjust placement to ensure wig is on securely and evenly. **Do NOT pull or tug the front edge to adjust.** Use bendable side tabs to adjust and form to the shape of your temples. If your wig is sliding around, tighten by moving back adjustments closer together. If your wig feels like it is popping up on top of head, loosen by moving adjustments farther apart.

- **If you have existing hair,** apply a fishnet wig liner before putting on your wig, wrap and tuck your hair through the opening in the back & tie the net closed. Adjust the liner past your hairline so it will not show when your wig is on.
- **For total hair loss,** wig may be directly worn over scalp. If your scalp is sensitive or perspires with wig wear, you may prefer to apply a cotton liner under your wig.

**SHAMPOO EVERY 6-8 WEARS:** Before washing your wig, gently remove any tangles with a wide tooth comb or a paddle brush. Fill sink with cool water and submerge wig. Emulsify a capful of **Argan Smooth Luxury Shampoo** into the hair. Gently lather the hair with shampoo, making sure that the hair is traveling in the same direction. **DO NOT** rub hair as it may cause tangling. Rinse thoroughly in cool water until water runs clear. Gently shake out any excess water. Wrap wig in a towel and gently pat dry. Apply **Argan Smooth Luxury Conditioner**, carefully avoiding the base of the cap (roots) as this may loosen the knots that keep the hairs attached. With fingers, work conditioner through ends of hair for 3-5 minutes. Rinse thoroughly in cold water until water runs clear. Wrap wig in a towel & gently pat to remove excess water. Use a wide tooth comb only to gently remove tangles. Use **Argan Smooth Treatment Mist** to speed drying time and smooth hair. Use a hair dryer on medium to medium-high heat & a boar bristle brush, working on 2 inch sections at a time, starting at the nape. Work in downward motion to keep hair smooth. Blow dry until completely dry. **DEEP CONDITION** every 3-5 washes, deep condition your wig to control flyaways and shield its color. Blend 1-2 pumps of **Argan Smooth Treatment Mist** with **Blow Dry Balm** and apply to the bottom half of the hair, keeping it away from the base of the cap. Use wide tooth comb to distribute throughout the ends. Cover wig with a plastic shower cap & leave in for 20 minutes or more before rinsing thoroughly in cool water until water runs clear.

**STYLING A HUMAN HAIR WIG:** Use only professional grade heat styling tools, set no higher than 350 degrees. Spray Heat Treat Thermal Spray on each 1 to 2-inch section starting at nape. When curling, you can use small metal clips to hold each curl while cooling for a tighter, longer lasting curl. For looser curl, allow curl to hang while cooling.

**I have been instructed on the proper wear and care of my wig. I understand that my wig purchase is final and I cannot return or exchange my wig.**

Signature: \_\_\_\_\_ Date: \_\_\_\_\_

**For normal care of your wig, you will need: Shampoo, Conditioner, Heat Treat Thermal Spray, Argan Treatment Mist, wide tooth comb, Wig Stand/Canvas Head with clamp.** *Additional items you may want:* Fishnet or Cotton Liners, Blow Dry Balm, Holding Spray, Pins, Boar Bristle Round Brush, Chin Strap & Clips for Styling. Hair pieces (bangs & face framers for wear with hats,) sleeper hats, headbands, scarves, and a wide variety of hats are also available.

Visit the Resource Page at [www.fittingsbymichele.com](http://www.fittingsbymichele.com) for additional information and how-to videos